



# Brewista Smart Scale II - 2020 Edition

With automatic taring, automatic timing, a 2kg weighing capacity, and 0.1 gram accuracy, the Brewista Smart Scale II has been specifically designed for the barista. Redesigned to include 6 easy-to-use modes and a rechargeable battery, the Brewista Smart Scale II is perfect for both espresso and pour over brewing methods. Featuring a rechargeable Lithium-ion battery with an included USB cable, an easy-to-read backlit LCD display, a protective silicone pad, and a water-resistant coating, the Brewista Smart Scale II is one of the smartest scales on the market.

**Mode 1:** Fully manual mode - User tares & starts timer manually.

**Mode 2:** Espresso mode - Auto-tare and auto-timer with immediate timer start.

**Mode 3:** Espresso mode - Auto-tare with manual-timer start.

**Mode 4:** Espresso mode - Auto-tare only, timer is not active.

**Mode 5:** Espresso mode - Auto-tare and auto-timer when liquid hits the cup.

**Mode 6:** Pour Over mode - Manual tare and timer functions.

## Features:

- Rechargeable Lithium-ion battery (USB cable included)
- Easy to read, backlit LCD display
- Water resistant nano-coating
- Protective silicone pad
- Large protective cover (can also be used as a weighing tray)
- Weighing capacity: 2000gms
- Accuracy: 0.1gm
- Auto-off function



**BSSRB2**  
Brewista Smart Scale II



# Mode Overview

## Mode 1:

- Mode 1 is the fully manual mode, with no automatic functions.
- You can time the extraction and find the tare using the appropriate buttons.
- The timer is paused and restarted by pressing TIME.

## Mode 2:

- Mode 2 is for making espresso, with an auto-tare, and auto-timer.
- Place cup on platform, and the display will flash once.
- The scale will automatically TARE and the timer will automatically start counting up from 0.
- The weight will be displayed as the shot is added into the cup.
- After you remove the cup, the time and weight are displayed for 5 seconds, then both will return to zero.

## Mode 3:

- Mode 3 is for making espresso, with an auto-tare and manual timer start.
- Similarly to mode 2, the scale will auto-tare when you place the cup on the platform.
- Press start on your espresso machine and TIME on your scale simultaneously.
- The timer will begin to count up and the weight will be displayed.
- Remove the cup and the last time and weight will be displayed for 5 seconds, then return to zero.

## Mode 4:

- Mode 4 is also for making espresso, with an auto-tare only. The timer for this mode is not active.
- Place cup on scale platform.
- The weight will tare automatically and will be displayed as added.
- Remove the cup and the last weight will be displayed for 5 seconds, then return to zero.

## Mode 5:

- Mode 5 is used for making espresso.
- It auto-tares when you place the cup on the platform, but only automatically starts timing when the extraction hits the cup.
- As per all previous modes, the weight is displayed as it is added to the cup, and will be displayed for 5 seconds then return to zero.

## Mode 6:

- The sixth and final mode is for pour over brewing, with auto-tare and auto-time functions at the time you need them for a pour over.
- Place the brewing vessel on the platform, and the weight will auto-tare.
- Add your coffee grounds to your desired amount and press TARE to zero out the weight.
- Start adding your water. The display will flash once and the timer will start automatically.
- As you continue adding water, the weight will be displayed.
- When you reach desired brewing time, remove the vessel. The time and weight will be displayed for 5 seconds, then return to zero.